

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижегород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://eijkelkamp.nt-rt.ru/> || emi@nt-rt.ru

Hand-operated foot valve pump set



12.13

The hand-operated foot valve pump set with a tripod is used for well development, purging of the monitoring well filters, and for sampling these wells up to 164 feet (50 meter). The diameter of the monitoring well varies from 0.9 inch (25 millimeter) to 5.9 inch (150 millimeter). It is also used for the sampling of both volatile substances and trace elements.

- For volatiles as well as trace metal sampling
- Compatible with all other types of analyses
- Can be used in monitoring wells of 0.9 to 5.9 inch in diameter
- Uses law of inertia to pump tenths of meter

Description

The foot valve pump consists of a tube with a ball valve and a tripod with lever. There are two sizes of ball valves: 0.7 inch (18 millimeter) external for tube 0.4 x 0.6 inch (12 x 16 millimeter) and 0.4 inch (12 millimeter) external for low-cost replaceable LDPE tube 0.31 x 0.39 inch (8 x 10 millimeter)

Method

Once submerged in water, the tube should be moved up- and downward relatively fast. By connecting the tubes to a lever, the weight of the water-filled tubes will be reversed so that you need not carry the weight. On the contrary, your arm will be lifted slightly. This way pumping requires little effort and can be sustained much longer. You can stand upright during the operation, so an ergonomically sound movement is guaranteed. In between, you also have the opportunity to rest. The foot valve pump has no suction, so no water level depth limit.

The hinge point of the lever can be moved quickly, in this way the stroke lever ratio can be adjusted which makes it possible to work efficiently at all times. The lever hinges on a tripod of which the height can be adjusted. This makes it possible to take samples from wells fitted with a shaft type well cover, as well as street type well covers.

The tube connection is universal; different sizes of tubes and valves can be applied. The tube should at least have the rigidity of polyethylene. Also, PTFE (polytetrafluoroethylene) tubes can be used.

Please note that when you install a pipe instead of a tube you can also use this device in larger wells. When pump movement is situated in filter section of well, the water is very turbid.

Applications

- Monitoring well installation
- Water quality research
- Monitoring water quality
- Anaerobe sampling
- Water sampling
- Ground water sampling

Set contains

- Hand operated foot valve pump
- Tube guide
- Ball valve for external tube 0.7 inch (18 millimeter), for tube 0.4 inch (12 millimeter)
- PE tube diameter 0.4 x 0.6 inch (12 x 16 millimeter)
- Aluminum tripod

Specifications

Hand-operated foot valve pump set

Fit for silt loaden water	Yes
Maximum pumping capacity	7 l/min
Maximum sample depth	164 feet 50 m
Power supply	Manual
Sample diameter	0.7 inch 18 mm
Package size	57.4 x 24.4 x 15.7 inch 146 x 62 x 40 cm
Weight	30.8 lbs 14 kg

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

